



# Digital Video Indoor Monitor


## Quick user guide

RoHS



# 一、Indoor Monitor Overview


## 1.1 Schematic plan view



Function Description		
① microphone	② power	③ bracket position

Technical Parameters			
Operating Voltage	DC 13-17V(G2) DC 20-24V ( G2.2 )	Operating temperature	-20-55℃
Standby Current	230mA	Standby power consumption	3W
Working current	320mA	Talk mode	dual


## 1.2 Installation steps







Mark installation position→Insert anchor→Fix bracket→Aim and hang

## 二、Indoor Monitor operating instructions

### 2.1 Main interface




Status prompt	Gray icon
 The internet	Network Issue
 Alarm	No alarm information
 Message	No message
 Ringtone	Do Not Disturb mode




## 2.2 User Settings

1




2




Enter the 4-digit password  
default password: 1234


3





Return



Choose your favorite ringtones






Enter the 4-digit password, you can reset a new password




Choose your favorite ringtone and volume

## 2.3 Monitor




- Unlock

4




Display the QR code of the outdoor station


5



Install CCL-SH APP on your phone,  
click on the main interface "Bind Device",  
scan the QR code of the outdoor station to  
bind the device.






CCL-SHAPP



QR code on the back of  
the outdoor station

## 2.4 Log

1






▼ ▲ Up / Down select


 Image Information

## 2.5 Config



1











For project operation only.  
Default password: 6666


























### 三、Wifi Setup


- Step 1: Open the APP CCL-SH , apply for registration account login, then switch to the mobile phone WIFI settings and connect to SSID, the SSID name is "happy2\_\*\*\*\*\*\_\*\*\*\*";
- Step 2: After successful connection, switch to CCL-SH main interface and click "Search for new device", pop-up prompt "Connected with device", click "Confirm" next
- Step 3: Select the WIFI signal in the pop-up available network, enter the corresponding WIFI password and wait to complete the configuration; operate in the following sequence.




1



2



3




4





## ② Apply to sign up a new account




- Open CCL-SH , sign up a new account, fill out the basic information to complete the registration.

## ③ Login



- Sign up finished, log in APP, enter the main interface.

## ④ Binding outdoor station



CCL-SH APP

QR code on the back of the outdoor station

- Click the Bind Decice button, Scan the QR code on the back of the outdoor station to bind the device or manually enter the mac address and activation code to bind the outdoor station.