



SD5C-G2

# Digital Outdoor Station Quick user Guide RoHS 🗵

• Schematic diagram

SAC65-G2 SAC65-G2.2

155x98x35 (mm)



SD5C-G2

155x62x42 (mm)



## • Wiring diagram



SAC65C-G2.2



SD5C-G2



• SAC65-G2 System diagram



## • SAC65-G2.2 System diagram





SD5C-G2 Installation



SAC65 Installation



### **CCL-SH APP Operation**

1、CCL-SH APP download and installation

Method 1 : Scan the QR code to download CCL-SH APP.





- Method 2 : Android: Google Play , search CCL-SH app. iOS: App Store, search CCL-SH app.
- Notice : 1. Android running version 6.0 and above.
  - 2. iOS running version 9.0 and above.
- 2、CCL-SH APP register
  - ▲ Open CCL-SH app (Image 1) , and click create account.
  - ▲ Fill out and complete the registration (User name, password, email, cell phone number)(Image2)

Notice: Please remember your password !



(Image1)



```
(Image2)
```

3、CCL-SH APP and add outdoor station

 $\blacktriangle$ Click  $\bigcirc$  on the upper left corner (Image 9).

 $\blacktriangle$  Scan the QR code of the outdoor station to bind the device (Image10) .







QR code of outdoor station

(Image 9)



▲Binding succeeded : " Outdoor C04LD-00231631980E

" Outdoor C04LD-00231631980D " (Image 11)

Green light 🤍 : The outdoor station is online status.

Red light 🧶 : The outdoor station is offline status.





- 4、CCL-SH APP to unlock door
  - ▲ Click 🖯 (Image 12). Pop-up dialogue box.
  - ▲Click 
    <sup>(1)</sup> to unlock the first lock (Image 13)
  - ▲Click 🐵 to unlock the second lock (Image 14)







(Image 12)

(Image 13)



- 5、Intercom setting
  - ▲ Click 🦉 on the upper right corner (Image 15)
  - ▲Click " 🌽 Cloud Call Setting " (Image 16)
  - ▲The mobile phone number is the registered phone number.

Enter room number 0101 and click bind (Image 17).

Notice: For villa system, room number is 0101 only.







(Image 15)

(Image 16)

(Image 17)

6、Intercom

▲Outdoor station and indoor monitor

Press call button (), indoor monitor and app will ring separately.

▲Outdoor station and Android indoor monitor

Press call button (2), indoor monitor and app will ring separately.

▲Outdoor station only

Press call button (a) , app will ring.

▲ Main interface of intercom (Image 12)

①.A visitor' s picture

- ②.Press 🔇 to pick up the call and talk with the visitor
- ③.Press 👝 to hang up the call
- ④.Press 🚹 to open the first door
- ⑤.Press 🔐 to open the second door



(Image 18)

▲Check visitors' pictures

Click 菖 (Image 19), click date and check pictures

(Image 20 , 21 and 22)

• Outdoor 0023205D9819 V				📢 20055 🔹 0door 002320509819 🗸 🛛 🏮								€ 258) ● 0:3600r 002320509819 ♥							€ 2946) ● Outdoor 002320509819 ♥ 0						
2022				Sun	Mon	Tue	Wed	Thu	Fri	Sat		Sun	Mon	Tue	Wed	Thu	Ri	Sat	Sun	Mon	Tue	Wed	Thu	Fri	Sat
JAN	FEB	MAR				FEB						20	21	22	23	24	25	26	20	21	22	23	24	25	26
23456	1 1 2 3 4 1 7 8 6 7 8 9 10 11 1	1 2 3 4 5 2 6 7 8 9 10 11 12				1	2	3	4	5		00:00		-					00:00		-				
9 10 11 12 13 16 17 18 19 20	14 15 13 14 15 16 17 18 1 21 22 20 21 😨 23 24 25 2	13 14 15 16 17 18 19 20 21 22 23 24 25 26		6	7	8	9	10	11	12		an an -							an an -		2023	2/01/22 19	i:16:41		]
23 24 25 26 27 30 31	28 29 27 28	27 28 29 30 31		13	14	15	16	17	18	19										_					
APR	MAY	JUN		20	21	22	23	24	25	26		02:00 -							02:00 -						-
3 4 5 6 7 10 11 12 13 14 17 18 19 20 21 24 25 26 27 28	8 0 8 9 10 11 12 13 1 15 16 15 16 17 18 19 20 2 22 23 22 23 24 25 26 27 2 29 30 29 30 31	4 5 6 7 8 9 10 11 1 12 13 14 15 16 17 18 8 19 20 21 22 23 24 25 26 27 28 29 30		27	28		•					03:00			1				03:00	•					-
	ALIC	SED				MAR						04:00 -	1						04:00 -	_					-
JUL	12 123454	3CP 123				1	2	3	4	5															
3 4 5 6 7 10 11 12 13 14 17 18 19 20 21	0         0         7         0         10         11         12         1           15         16         14         15         16         17         18         19         2           22         23         21         22         23         24         25         26         2           38         38         16         36         31         31	3         4         5         6         7         8         9         10           0         11         12         13         14         15         16         17           7         18         19         20         21         22         23         24           18         19         20         21         22         23         24		6	7	8	9	10	11	12		06.00							06.00						
31				13	14	15	16	17	18	19															
OCT	NOV	DEC 1.2.3		20	21	22	23	24	25	26		07:00 -							07:00 -						
2 3 4 5 6 9 10 11 12 13 16 17 18 19 20 23 24 25 26 27	7 8 6 7 8 9 10 11 1 14 15 13 14 15 16 17 18 7 21 22 20 21 22 23 24 25 2 28 29 27 28 29 30	2 4 5 6 7 8 9 10 9 11 12 13 14 15 16 17 6 18 19 20 21 22 23 24 25 26 27 29 29 30 31		27	28	29	30	31				08:00 -							08:00 -						
Smart Home		amony Option				5	p		~	Option	_	Court I		5	D.r	Ē			Court I	Luna	5	D.r			
(I		(Image 20)								(Image 21)							(Image 22)								

- 7、Monitor
  - Press 🕻

▲ Monitor from the camera of the outdoor station

- ▲ Talk with the visitor by the outdoor station
- $\blacktriangle$  Click A to unlock the first lock (Image 23)
- $\blacktriangle$  Click 6 to unlock the second lock (Image 23)



(Image 23)

8, Authorize new users

Method 1: Scan QR code

- ▲Click 🙋 on the upper right corner
- ▲ Click Share Device (Image 25)
- ▲ Scan new user 's QR code in the CCL-SH app. Choose the device to be authorized.

Click OK (Image 26)

Choose the time to be authorized. Click OK (Image 27).



(Image 24)

(Image 25)

(Image 26)

(Image 27)

Notice: How to find new user 's QR code in the app?

 $\blacktriangle$  Click on the upper right corner (Image 28).

(Image 30). This is the user QR code (Image 31).



(Image 28)

(Image 29)

(Image 30)

(Image 31)

Method 2 : Enter new user 's share code

- ▲ Click 🔯 on the upper right corner (Image 32)
- ▲ Click < Share Device (Image 33)
- ▲ Click Input Share Code (Image 34)
- ▲ Paste the new user 's share code (Image 35)



(Image 32)

(Image 33)

(Image 34)



Notice: How to find new user 's share code in the app

▲Click 📫

on the upper right corner (Image 36).



▲Click My Share Code (Image 38). This is the user share code (Image 39).



(Image 36)

(Image 37)

(Image 38)

(Image 39)

- 9、 List of the new users
  - ▲ Click **O** on the upper right corner (Image 40)
  - ▲Click 🔡 Share List

(Image 41) to check the list of the new users of this device.







(Image 40)

(Image 41)

(Image 42)

#### ▲Click 🙋 to modify (Image 43 & 44)



(Image 43)



(Image 44)

▲ Click 📶 to delete the share (Image 45)



(Image 45)

- 10、Delete device
  - ▲ Click Ouldoor 00231631980D on the top of the front page. Choose the device for deletion (Image 46)
  - ▲ Click 🔅 . Click 🛅 Delete Device (Image 47)
  - ▲ Click OK in the pop-up dialogue box (Image 48)



(Image46)



(Image 47)



(Image 48)

#### 11、Modify device name

- ▲ Click Outdoor 002346D19810 on the upper right corner and choose the device to change name (Image 49)
- ▲Click 🚺 . Click 🜔 Device Name (Image 50)
- ▲ Enter the new name of the device (Image 51). Click SEND. The name is modified (Image 52).



(Image 49)

(Image 50)



(Image 52)

12、Forget password

Forget login password ?

- ▲ Click FORGOT PASSWORD? in the login page (Image 53)
- ▲ Enter email address or user name. Click SEND. The reset password email will be sent (Image 54).





(Image 53)

(Image 54)